

ECGR 4101/5101 -

LECTURE 16

SPI is good for short distances

Problems with high speed:

- \* Noise

- \* Impedance

- \* reflection

You should only communicate at the  
max speed you need