
The Travel Pod™



How to Use:

In the package the travel box came in you should have received two parts. There should be a cap and the main container body. The body has 5 compartments for various toiletries including a toothbrush, toothbrush, toothpaste, razor, and comb.

Use for Travel:

The cap can slide on to protect the contents of the travel box as shown in figure 1. Once the cab is slid onto the container, the travel box can fit in a pocket or in a backpack or in other luggage.




Figure 1:

Use at the Sink:

After you arrive at your destination, the travel box can be placed vertically on top of a counter. To access your toiletries, remove the cap as shown in figure 1. Once your items are used, they can be placed back in the Travel Pod to be used later.

Cleaning and Maintenance Guide:

To clean the travel pod you can either use a rag or sponge or the dishwasher. When cleaning you can put dish soap on a rag, and you can rinse out the travel pod with water. Apply the cleaning rag to the internal sections of the travel pod as seen in figure 2.

When cleaning in a dish washer place on the top rack. If placed on the lowest rack the plastic could deform due to prolonged exposure to heat.




Figure 2:

Safety:

Although the travel pod may protect your items from splashes of water, it is not waterproof. The travel pod will not protect your items if submerged in water.

If the Travel Pod is exposed to excess stress it may break. Do not attempt to repair it. The fragments may be sharp and pose a health hazard.

The Travel Pod can be safely disposed of in the trash once the product has lived its life cycle.

Warranty:

If the travel has a defect, email our customer support team.

Devon Swan	dswan5@charlotte.edu
Will Adermann	waderman@charlotte.edu
Daniel Jetzer	djetzer@charlotte.edu

We will replace your product after the 1st year at no extra cost. If the product is modified in any way, the warrant is voided.